

smoothskins

Autocare Systems

Installation Instructions – Velcro Method

Notes:

1. Remove boot privacy blind if applicable; this will refit on completion of installation.
2. Remove any dirt, dust etc. from carpeted areas of the boot (including seat backs).

FITTING SEAT BACK PANELS

- Place seats in horizontal (flat) position
- Identify (using CONTENTS LIST) which panel fits which seat back
- Place panels in position, following the shape of the seats
- Place seats in upright position as far back as they will go

FITTING SIDE PANELS

- Identify (using CONTENTS LIST) the LEFT and RIGHT side panels, as viewed from the rear of the vehicle
- Follow the shape of the side panels, ensuring the back edge follows the angle of the seat back.
- Once the Velcro has gripped the panel, smooth out by hand

BOOT FLOOR MAT & BUMPER PROTECTOR

- Place in position, pushed up against rear seats
- Smooth sides in to position (Your Bumper protection is already attached to the boot mat with Velcro – please ensure it is folded in to the boot area and the boot catch lock is not impeded by the protector)

Any problems, call our helpline on 07017 426 121

www.smoothskins.co.uk

Unit 1 - Cleadon Lane Industrial Estate-East Boldon-Tyne and Wear-NE36 0AH